


BLADE INSTALLATION & FAN BALANCING

BLADE INSTALLATION

- Match the serial number on the blades with the serial number on the motor.
- Match the colour on the blades with the colour on the motor.



FAN IMBALANCE

In the unlikely event of your fan running unbalanced after installation, or after a period of time, there is now an easy way to re-balance.

- Switch off fan
- Use a measuring tape or a carpenters square to measure the distance between ceiling and the tip of fan blade as show in diagram (B).
- Mark on tape or square and repeat with other two blades.
- Using your hands, carefully bend the blade shank (A) and NOT the blade, in the required direction until all three blade tips measure precisely the same distance to the ceiling (B).
- Your fan should now run smooth and balanced.

